



[More gouge on Reef Points](#)

Print Page  E-mail Page

## **Gentlemen (and Ladies)! Start Your Engines!**

By Vincent Pica

We've talked about how to get the boat ready for a long, cold and dank winter ("Winterizing Your Boat,"). In spring, time and tide is finally on our side. When Memorial Day weekend is only a couple of weeks away, and BEFORE you start your engines, ready the boat!

### **Getting Started**

As with any project, starting at the beginning is best. And for "commissioning," i.e., getting the boat ready for service, the beginning is the front of the boat. For those that trailer their boats, the front of the boat is the trailer. Who wants to go flying down Rte. 27 and see their boat doing somersaults along the side of the road? How do you prevent that?! Well, start with the strap that comes out of the winch. Connected to the bow eye, it is the first line of defense. Pay out a few feet and make sure that there aren't any frayed or torn segments. If there are, you'll need to cut out that entire segment and re-attach the strap. If you aren't sure how – and you need to be since this strap is the first line of defense – get help from a competent mechanic or dock master.

While you're at it, why not spray the winch and all the moving parts with some penetrating oil? Pay out the entire strap if need be and recoil it up so that you are sure you get a good covering of the moving parts with penetrating oil. Take a walk around the boat and be sure the binding straps are all equally in good shape. If not, replace them.



*Safe Boating Begins  
at the Dock.*

As to the boat itself now, open the anchor locker and flake out the anchor rode (the line and chain attaching the anchor to the "eye" in the bottom of your anchor locker/your boat) and lay the anchor "on the hard." Again, check the shackles for excessive wear as well as the rode itself. Replace or repair, as needed. No sense having the boat float away one day because the anchor rode wore through or a shackle pin gave out.

Be sure that the navigation lights (red and green) are working. If not, take the bulb with you to the marine hardware store and replace it – and get spares. The gas is more expensive than a few extra bulbs.

Your storage area(s) might be forward so open them up and ensure that PFDs, tools, etc., are all in good condition. Check that there is no standing water in the compartment. If so, the "limber holes" are clogged and the water can't get to the bilge to be pumped overboard. Every ounce of weight that wasn't on the boat when the boat was manufactured changes its centers of buoyancy and gravity. In heavy seas, that just might matter a whole lot.

Next is the cockpit and the electronics. Disconnect them, spray them with some "white grease," then reconnect and test the gear. If a connector is corroded, replace it. These steps will keep salt in

the air from penetrating your electronics.

If you haven't checked the PFDs yet, do so now. Check your whistle, your horn, your flares – any and all safety equipment. Don't forget your fire extinguisher(s). If it isn't "in the green," chuck it. Also, gently shake it side to side, head over end. If you hear a "thunk," the dry chemical has solidified. It would now make a good door stopper but not much else. You should hear a low "ssh..." sound as the suppressant moves back and forth.

Check the fuel tank. Is the "sender wire" (which runs from the top of the tank – usually – to the fuel gauge) in good condition? How about the filter? Check the fuel lines too. Weak or cracked hoses must be replaced, along with rusted hose clamps. Stainless steel.

How is the battery – and the clamps that attach to the posts? Just like a car, all this has to be in good condition.

The engine is the most obvious component to ready for service. Change the oil – all the oil – including the oil down in the foot of the engine. You'll need a large straight-slot screwdriver for the two screws (high and low) that have to be backed out, a bucket and a quart of oil. Find all the grease fittings and gently pump new grease in until it comes out somewhere else. Don't forget the steering cable fitting. Be sure that the oil dipstick is properly seated.

BTW, if you do have trailer, check the tires and the lube the bearings. As with the engine grease, pump it in gently. Who wants to push out a seal?

Reset the spark plug(s) in the engine before you put the cover back on – unless you are going to work on the prop. Some old models might start up when you turn the prop – and that will definitely ruin your Saturday. Once ready to start the boat, be sure it is in water! You need the coolant! It will smoke at first from the fogging oil you laid in the fall but that will quickly pass.

Okay, there are surely more things to do, but you're well on your way to heading out to the high seas – or at least Moriches Bay!

**About the Author:** *Vincent Pica is a coxswain and the Commander of Flotilla 18-06 East Moriches. He was a navigator in a brown-water and blue-water sailboat racing crew for eight seasons. From the "iron sails" side, he is a licensed US Coast Guard Master of Steam and Diesel Powered Vessels, carries a Radar Observer endorsement, Unlimited, on his license and is certified in Marine Diesel Engine Operation and Maintenance.*

**Have something to say? [Sound off](#) on the Squawk Box.**



**Rating:** ★★★★★



**SUBMIT**



© 2008 U.S. NAVAL INSTITUTE